

# **FPS** MH series

**Exploded view  
parts diagram  
3, 5, 9 m<sup>3</sup>h**





# MH Pumps Spare Parts

REF.N.	DESCRIPTION	CODE	MODEL		
			MH 3	MH 5	MH 9
10 00	Terminal box cover				
	Single Phase MEC71	2851200	3/2-3-4-5-6-7	5/2-3-4-5	9/2-3
	Three Phase MEC 71	2851210			
	Single Phase MEC71	2851220	3/8-9	5/6-7-8-9	9/4-5-6
	Three Phase MEC80	2851230			
			MH 3	MH 5	MH 9
20 00	Pump casing	15401105	3/2-3 M-T	5/2-3 M-T	
		15401115	3/4 M-T	5/4 M-T	
	M = Mono Phase/Single phase	15401125	3/5 M-T	5/5 M-T	
		15401135	3/6 M-T	5/6 M-T	
	T - Tri-Phase/3 Phase	15401145	3/7 M-T	5/7 M-T	
		15401155			9/2-3 M-T
		15401165			9/4 M-T
		15401175			9/5 T
		15401205	3/8 M-T	5/8 M-T	
		15401215	3/9 M-T	5/9 T	
					9/6 T
			MH 3	MH 5	MH 9
20 01	Motor bracket				
	MEC71	16919514	3/2-3-4-5-6-7 M-T	5/2-3-4-5 M-T	9/2-3 M-T
	MEC80	16919515	3/8-9 M-T	5/6-7-8-9 M-T	9/4-5-6 M-T
	MEC90	16919516	na	na	na
20 02	Seal housing	16100014		ALL MODELS	
20 03	Screw for pump casing (8 pcs needed)	240308		ALL MODELS	
20 04	Support foot	16150410		ALL MODELS	
20 05	Filling and drain plug without O-Ring (2 pcs needed)	264011		ALL MODELS	
			MH 3	MH 5	MH 9
30 00	Motor housing and stator	14062100	3/2-3-4-5 M	5/2-3 M	9/2 M
		14062110	3/2-3-4-5 T	5/2-3 T	9/2 T
	M = Mono Phase/Single phase	14062120	3/6-7 M	5/4-5 M	3/3 M
		14062130	3/6-7 T	5/4-5 T	9/3 T
	T - Tri-Phase/3 Phase	14062140	3/8-9 M	5/6-7-8-9 M	9/4 M
		14062150	3/8-9 T	5/6-7-8-9 T	9/4-5-6 T
			MH 3	MH 5	MH 9
30 01	Bearing housing	16919550	3/2-3-4-5-6-7 M-T	5/2-3-4-5 M-T	9/2-3 M-T
		16919551	3/8-9 M-T	5/6-7-8-9 M-T	9/4-5-6 M-T
			MH 3	MH 5	MH 9
30 02	Fan	16070500	3/2-3-4-5-6-7 M-T	5/2-3-4-5 M-T	9/2-3 M-T
		16070505	3/8-9 M-T	5/6-7-8-9 M-T	9/4-5-6 M-T
30 03	Fan cover	16420800	3/2-3-4-5-6-7 M-T	5/2-3-4-5 M-T	9/2-3 M-T
		16420805	3/8-9 M-T	5/6-7-8-9 M-T	9/4-5-6 M-T
30 04	Tie rod (4 pcs needed)	16710700	3/2-3-4-5-6-7 M-T	5/2-3-4-5 M-T	9/2-3 M-T
		16710705	3/8-9 M-T	5/6-7-8-9 M-T	9/4-5-6 M-T

# MH Pumps Spare Parts (continued)

REF.N.	DESCRIPTION	CODE	MODEL		
			MH 3	MH 5	MH 9
30 05	Kit O-ring (3 pcs)	14221006	ALL MODELS		
30 06	Kit mechanical seals (3 pcs)	14222009	ALL MODELS		
			MH 3	MH 5	MH 9
30 07	Kit ball bearings and lip seal (2+2pcs)				
	MEC71	14231007	3/2-3-4-5-6-7 M-T	5/2-3-4-5 M-T	9/2-3 M-T
	MEC80	14231008	3/8-9 M-T	5/6-7-8-9 M-T	9/4-5-6 M-T
			MH 3	MH 5	MH 9
30 08	Rotor and pump shaft	14600900	3/2-3 M-T	5/2-3 M-T	
		14600905			9/2 M-T
	M = Mono Phase/Single phase	14600910	3/4 M-T		
		14600915		5/4 M-T	
	T - Tri-Phase/3 Phase	14600920			9/3 M-T
		14600925	3/5 M-T		
		14600930		5/5 M-T	
		14600935			9/4 M
		14600940			9/4 T
		14600945	3/6 M-T		
		14600950		5/6 M	
		14600955		5/6 T	
		14600960			9/5 T
		14600965	3/7 M-T		
		14600970		5/7 M	
		14600975		5/7 T	
		14600980			9/6 T
		14600985	3/8 M	5/8 M	
		14600990	3/8 T	5/8 T	
		14600995	3/9 M		
		14600996	3/9 T	5/9 T	
30 09	Kit screws, nuts and washers	14240035	ALL MODELS		
40 00	Stage housing and diffuser	14281254	MH 3 - MH 5		
		14281243	MH 9		
40 01	Last stage with hole	14285211	MH 3 - MH 5		
		14285212	MH 9		
40 02	Floating neck ring assembly	15860203	MH 3 - MH 5		
		15860204	MH 9		
40 03	Initial stage housing	14280222	MH 3 - MH 5		
		14280243	MH 9		
50 00	Impeller	15070400	MH 3		
		15070401	MH 5		
		15070402	MH 9		
50 01	Impeller spacer (2 pcs needed for each impeller)	16120310	MH 3 - MH 5		
		16120312	MH 9		





## **Franklin Electric**

Franklin Electric (Aust) Pty Ltd  
106-110 Micro Circuit  
Dandenong South, Vic 3175  
Tel: +61 3 9799 5000

**Toll Free: 1300 FRANKLIN**  
1300 372 655

**[franklinwater.com/au](http://franklinwater.com/au)**

**UNITED STATES**  
9255 Coverdale Road  
Fort Wayne, IN 46809  
Phone: +1.260.824.2900  
Fax: +1.260.824.2909